

Horizontal Machining Center HX-204 Maintenance Manual

Page 1: Overview & Specs

Spindle Speed: 12,000 RPM maximum. Tool Taper: BT40. Coolant Pressure: 20 bar.

Acceptable Spindle Runout: 5 μ m maximum allowable tolerance.

Oil Type: ISO VG 32. Bearing replacement interval: 8,000 operational hours.

Page 2: Troubleshooting & Repair Steps

If abnormal noise or spindle runout exceeds 5 μm , lock out power and inspect spindle seal and bearing alignment. Replace seal if worn. Reassemble housing cover and test run at 2,000 RPM increments.